

Input
- Button Start
- Button Reset
- Button Set
- Potentiometer
- Preset 1-3



Output
- 8 digit 7-segment display
- buzzer
- VFD
- D0 - D2
- FWD
- Control lamp 1 - 2

mode:
CONFIGURE

mode:
MEASURE_MANUAL

mode:
MEASURE_AUTO

reset counter and stop motor
in any situation



start counting (pull and attach wire manually to spool)